

1. Strip insulation from wire (approximately 3/8").

Insert wire in holder.

3. Crimp terminal through body.4. Repeat steps 1 – 3 for other half of holder.

5. Insert fuse.6. Snap housing together.