



Drill hole same size as nylon anchor. Set anchor in hole. Insert nail and drive flush with top of anchor.