


1. Drill hole. Install anchor flush or slightly below surface.



2. Insert lag screw through fixture into anchor and tighten.