



1. Drill hole of proper diameter in concrete. Drilled hole can be any depth beyond minimum recommended depth.
2. Drive Wedge Anchor into drilled hole through fixture until nut is flush with fixture.
3. Tighten nut until wrench resistance is felt (approximately three to four full turns past the hand-tight position). Anchoring is now complete.