



1) Insert one or more cables into the insertion slot of the applicator tool.



2) Place the applicator tool in one end of the split wire loom.



3) Slide the applicator tool through the split wire loom.